

ASSEMBLY INSTRUCTIONS

Assembly Checklist & Instructions

ENSURE YOU HAVE ALL PARTS

- 2 x poles (either 2m or 3m long)
- 2 x bases (25L capacity)
- Signage insert (Vinyl, ACM or Corflute)

FOLLOW ASSEMBLY INSTRUCTIONS BELOW

Estimated time: 5 minutes



1 Unscrew the top bolt using a 10mm hex key



2 Repeat the previous step for the bottom bolt



3 The base will easily detach from the aluminium rods



4 Slide the keder (banner) or the panel through the top and bottom channel



5 Attach the bases into the aluminium rods



6 Screw the top bolt using a 10mm hex key



7 Screw the bottom bolt using a 10mm hex key



8 Using an hex key, unscrew the water cap and fill up the bases



9 **DONE!**

WWW.20TWENTY.NET | 1300 91 31 81